

C-MF Tactor[†]

Product Data Sheet

EAI Tactor



[†] US patent 7,798,982

Specifications

<i>Physical Description:</i>	0.92" (23.4 mm) by 1.09" (27.6 mm) by 0.45" (11.4 mm) high
<i>Weight:</i>	8 grams (excluding lead)
<i>Exposed Material:</i>	Polycarbonate, Aluminum, PVC
<i>Electrical Wiring:</i>	Flexible, insulated, #26 AWG tinsel
<i>Body Contactor:</i>	0.2" (5.1 mm) diameter, pre-loaded on skin
<i>Tactile Pulse Characteristics:</i>	180-280 Hz, <2 ms rise time
<i>Electrical Characteristics:</i>	10 ohms nominal with 18" wire
<i>Recommended Drive:</i>	Sine wave tone bursts 250Hz at 0.25A rms nominal, 0.5A max for very short durations. Duty cycle < 10%.
<i>Recommended Controller:</i>	EAI Universal Controller, C15-8 Controller

Product Description

The C-MF tactor is a miniature vibrotactile transducer optimized for use on the fingertip. The housing is shaped to locate the fingertip over a small vibrating contactor. EAI's C-MF series Tactors are state-of-the-art, wearable vibrotactile transducers, suitable for a wide variety of biomedical and research applications.

Applications

- Tactile Research
- Tactor gloves
- Wearable tactile feedback
- Haptic feedback
- Virtual reality
- Medical
- Entertainment
- Gaming

Operation

The C-MF series tactors incorporate a moving "contactor" that is lightly preloaded against the fingertip. The C-MF housing is shaped with a convex curve to center the finger and the fingertip. The C-MF is intended to be pressed against the finger using a stretchable glove, finger cot or tape strap wound around the fingertip.




C-MF Tactor

When an electrical signal is applied, the “contactor” oscillates perpendicular to the skin, while the surrounding skin area is “shielded” with a passive housing. Thus, unlike most vibrational transducers (such as common eccentric mass motors that simply shake the entire device), the C-MF provides a strong point-like sensation that is easily felt and localized.

The C-MF has contactor that is sized so as to optimize the impedance transfer between the actuator and mechanical impedance of the fingertip.

To improve efficiency, the C-MF series tactors have a mechanical resonance in the 200-300 Hz range that coincides with peak sensitivity of the Pacinian corpuscle; one of the skin’s mechanoreceptors that sense vibration.

The C-MF series are recommended for use in applications requiring tactile feedback or stimulation of the fingertips.



Contact EAI for Additional Information

EAI offers complete turnkey vibrotactile systems and a range of tactors products – please contact us for details.



406 Live Oaks Boulevard, Casselberry, Florida 32707
email: sales@eaiinfo.com www.eaiinfo.com
phone: (407) 645-5444 fax: (407) 645-4910